


PRIROČNIK ZA NAMESTITEV / INSTRUCTION MANUAL

R LUM WALL



1. SPECIFIKACIJE / SPECIFICATION




MODEL	Moč / Power	Vhod / Input	Mere / Dimensions (mm)*	Teža / Weight	IP	T (°C)
R LUM W	8-10 W	220-240 VAC / 50/60 Hz	450/600	0,8	44	- 20 / + 55

* D x Š x V / L x W x H


2. KORAKI NAMESTITVE / INSTALLATION

Pri izdelku z drsnim stikalom za izbiro CCT pred namestitvijo izberite CCT (WW/NW/CW).
/ For the product with Slide Switch of CCT selection, please select the CCT (WW/NW/CW) before installation.



Namestitev na steno / Wall mounted installation

1.korak / Step 1




Iz škatle vzemite svetilko in komplet opreme. / Take out the lamp and accessory pack from the box.

2.korak / Step 2



Odstranite končni pokrovček v smeri puščice. / Take out the end cap according to the arrow direction.

3.korak / Step 3



Odstranite pokrov svetilke / Take the lamp cover apart.

4.korak / Step 4




V strop vstavite plastično sidro, skozi gumijasto objemko speljite žico za izmenični tok in ohišje svetilke pritrdite na strop. / Insert the plastic anchor into the ceiling, make AC wire through the rubber sleeve, fix the lamp body on the ceiling.

5.korak / Step 5




Ustrezno povežite žico za izmenični tok / Connect AC wire correspondingly. /

6.korak / Step 6




Na svetilko pritrdite pokrov svetilke. / Fasten the lamp cover on the lamp.

7.korak / Step 7




Na svetilko pritrdite končni pokrovček. / Fasten the end cap on the lamp.

8.korak / Step 8



Povežite moški in ženski priključek, vklopite / Connect male and female connector, turn on



9.korak / Step 9



Način namestitve: držite drsno stikalo navzdol / Way to install: keep slide switch downward

Navpična namestitve na steno / Vertical wall mounted

Vodoravna namestitve na steno / Horizontal wall mounted



Svetilo lahko popravlja ali vzdržuje le proizvajalec ali njegov servisni zastopnik ali usposobljen električar.
/ The luminaire should only be repaired or maintained by the manufacturer or his service agent or a qualified electrician.



Previdno, nevarnost električnega udara. / Caution, risk of electric shock.



Ta oznaka označuje, da tega izdelka ni dovoljeno odstranjevati z drugimi gospodinjskimi odpadki v EU. Da bi preprečili morebitno škodo za okolje ali zdravje ljudi zaradi nenadzorovanega odlaganja odpadkov, jih odgovorno reciklirajte in tako prispevajte k trajnostni ponovni uporabi materialnih virov. Če želite vrniti uporabljen napravo, se obrnite na prodajalca, pri katerem ste izdelek kupili. Ta izdelek lahko prevzame za recikliranje, namenjeno varstvu okolja. / This marking indicates that this product should not be disposed with other household wastes through the EU. To prevent possible harm to the environment or human health from the uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Opozorilo / warning:

1. Če je zunanji gibljivi kabel ali vrstica te svetilke poškodovana, jo mora zamenjati izključno proizvajalec ali njegov servisni zastopnik ali ustrezno usposobljena oseba, da se prepreči tveganje. / If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
2. Svetlobni vir v tem svetilu sme zamenjati zgolj proizvajalec, njegov zastopnik ali druga kvalificirana oseba. / The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.